



Setovanje barkod skenera da na kraju pročitano g koda pošalje samo jedan CR (Enter) kod.

Newland HR-100

Tools

Code Programming ON



Set Terminal as 0x0D and Enable Sending
【Pro CMD: 99904113】

Code Programming OFF



Newland HR-200

Code Programming ON



Program Stop Suffix



0




D



Save

Code Programming OFF



Allow Stop Suffix

